


COMPETITION

Intercom Series




Intercom Schematic

Dual Gate Station Series




CPT-GATE-A

Colour Video & 2-Way Voice Gate
Station with Access Control Keypad




Depth: 60mm max. including weather guard



A 12V power supply must be connected to the + 12VDC input (C) for the keypad to work. This can either be taken from the monitors power supply, down an extra wire or from the power supply that runs the door lock.

CPT-GATE-B



Colour Video & 2-Way Voice Gate Station



Depth = 40mm max. including weather guard

CPT-GATE-E

Flush Colour Video & 2-Way Voice Gate Station with Access Control Keypad



Connection Legend

⊕ = Talking volume adjustment trim pot

J3 = Door lock/relay 1

CNI = Indoor CPT monitor

J1 = Connect keypad/access control module

JP1 = Disconnect JP1 if used with keypad/access control

PWR = 12-24V power supply

J4 = Unlock button for REX1 & REX2

J1 = Look to connect to main board module

J3-1 = Door lock/relay 1

J3-2 = Connect relay 2

Depth: 54mm max. (if using CPT-GATE E SHROUD)

Programming the CPT-GATE-A



Changing the Master Code:

- Remove power from the unit,
- Then press and hold down the * button.
- Apply power, with the * button still held down, the unit will then give a long continuous tone.
- When the tone stops release the * button.
- Wait for the LED to start flashing.
- Now enter your new 4 digit code.

Entering Programming Mode:

- Press the * button
- Wait for a double beep.
- Then enter your 4 digit Master code.
- You should hear 3 beeps and the LED will flash Red.
- Now you are in Programming Mode.

Exiting Programming Mode:

- To exit programming mode just press the * button.

Adding User Codes:

- Enter Programming Mode.
- Choose the slot you wish the code to be stored in (01 to 40)
- You will hear a double beep
- Now enter the new 4 digit user code, if the code loads correctly
- 3 beeps will be heard. You can only load a code once.
- You can now load another code or exit programming mode.

Deleting User Codes:

- Enter Programming Mode.
- Press the # button, you will hear a double beep.
- Enter the 4 digit user code you wish to Delete,
- 3 beeps will be heard if the code is removed.
- You can now delete another code or exit programming mode.

Deleting User Codes by Slot:

- Enter Programming Mode.
- Choose the slot 01 to 40 that you wish to delete,
- You will hear a double beep.
- Now press the # Button to delete the code,
- 3 beeps will be heard if the code is removed.
- You can now delete another code or exit programming mode.

Setting the Lock Time:

- Enter Programming Mode.
- Press 0 0 (this selects a special timer location).
- Now Enter the desired 2 digit time 01 to 99 seconds
- You can now exit Programming Mode

Deleting All Settings:

- Enter Programming Mode.
 - Press the # Button Once, it will beep twice.
 - Press the # Button Once Again, it will beep twice again.
 - Now Press the # Button 7 more times, the LED will turn off and it will beep 4 times indicating the Reset has taken place.
- All information will be erased except the Master Code.

Slot	Code	Output
01		timer
02		timer
03		timer
04		timer
05		timer
06		timer
07		timer
08		timer
09		timer
10		timer
11		timer
12		timer
13		timer
14		timer
15		timer
16		timer
17		timer
18		timer
19		timer
20		timer

Slot	Code	Output
21		timer
22		timer
23		timer
24		timer
25		timer
26		timer
27		timer
28		timer
29		timer
30		timer
31		latching
32		latching
33		latching
34		latching
35		latching
36		latching
37		latching
38		latching
39		latching
40		latching

Programming the CPT-GATE-E



www.aap.co.nz

Entering Admin Mode:

- Default Admin Code: 1 2 3 4
- Enter your admin code twice: 1 2 3 4 1 2 3 4
- You will then get a long BEEP followed by a YELLOW steady LED
- The keypad will automatically exit programming after 20 seconds.

Exiting Admin Mode:

- Continue to press # until a solid BLUE LED is ON.

Adding User Codes to Relay 1:

- First enter Admin Mode
- Then press the slot you wish to load: 001 - 999;
 - Solid RED LED = Slot is full. Go to "Deleting User Slot"
 - Solid GREEN LED = Slot is empty and ready to accept code
- Enter new 4 digit code;
 - Long BEEP + solid YELLOW LED = Code successfully loaded.

Adding User Codes to Relay 2:

- First enter Admin Mode
- Press *4 (YELLOW LED Blinking)
- Then press the slot you wish to load: 01 - 09;
 - Solid RED LED = Slot is full. Go to "Deleting User Slot"
 - Solid GREEN LED = Slot is empty and ready to accept code
- Enter new 4 digit code;
 - Long BEEP + solid YELLOW LED = Code successfully loaded.

Deleting User from Relay 1:

- First enter Admin Mode
- Then press the slot you wish to load: 001 - 999'
 - Solid RED LED = Slot full.
 - Solid Green LED = Slot is empty, no need to delete code from slot providing the LED is RED. Press * twice. There will be a long BEEP followed by a solid GREEN LED.

Deleting User from Relay 2:

- First enter Admin Mode
- Press * 4
- Then press the slot you wish to load: 01 - 99;
 - Solid RED LED = Slot is full. Ready to delete
 - Solid GREEN LED = Slot is empty, no need to delete code from this slot providing the LED is RED. Press * twice. There will be a long BEEP followed by a solid GREEN LED.

Changing Relay 1 Reset Time:

- Enter Admin Mode
- Press * 1 (YELLOW flashing LED)
- Press the time in seconds (1-99) (YELLOW solid LED + long BEEP). Note: 00 = Latching

Changing Relay 2 Reset Time:

- Enter Admin Mode
- Press * 5 (YELLOW flashing LED)
- Press the time in seconds (1 - 99) (YELLOW solid LED + long BEEP). Note: 00 = Latching

Changing Admin Code:

- First enter Admin Code
- Press * 3 (YELLOW LED will blink)
- Followed by your new Admin Code twice (a total of 8 digits). Keypad will long BEEP followed by solid YELLOW LED.

Full System Default:

- Enter Admin Mode
- Press * 8 (YELLOW LED will blink)
- Press 88 (solid YELLOW LED + 6 short beeps followed by 1 long BEEP)
- Press * 8 again (flashing YELLOW LED)
- Press 99 (solid YELLOW LED) (delayed long BEEP).

Default Admin Code Only:

- Power down unit
- Power up while holding # (short BEEP + solid BLUE LED)
- Code will be back to the default of 1 2 3 4.

001 - 999 (Relay 1)


Slot	Code
001	
002	
003	
004	
005	
006	
007	
008	
009	
010	
011	
012	
013	
014	
015	
016	
017	
018	
019	
020	

01 - 09 (Relay 2)

Slot	Code
01	
02	
03	
04	
05	
06	
07	
08	
09	

CPT-MON-3



3.5" Colour Video & 2-Way Voice Monitor



Depth: 42mm including brackets


Jumper Settings

- J2 = Coax cable used
- J1 = The gate station will ring back when the button is pressed
- J3 = Feature not supported (can cause bad feedback)



CPT-MON-8W & CPT-MON-8B

7" Colour Video & 2-Way Voice Monitor




- Normally open momentary relay on back of monitor (secondary relay)
- Open camera feed
- Take a screenshot of image
- Relay on back of gate station
- Answer visitor call


Depth: 24mm max. including brackets

Jumper Settings

- J2 = Coax cable used
- J1 = The gate station will ring back when the button is pressed
- J3 = Feature not supported (can cause bad feedback)




Gate Station 1




Gate Station 2 (Optional)




WELL-LPV-20-15 Red = 15V DC
Black = 0V



Back of CPT-MON-8W



Note: each monitor requires its own power supply



CN2 is only wired if the second gate station is connected

Competition Wiring Diagrams

