

ECi
(248 Zone Control Communicator) **ECi**

Arrowhead
Alarm Products Ltd

Program Summary Guide

Proudly Designed and Manufactured in New Zealand

SOFTWARE VERSION

This manual relates to ECI control panels with software version **V10.3.47** and above

Special Programming Operating Procedures

Programming addresses that have 32 options (Areas, Outputs & Keypads)

When in Program mode there are many program addresses (eg P3E) where there are 32 options that can be selected. When in these locations the selection is always a two digit number, eg at P3E you can select up to 32 areas, if you wanted to select areas 1, 5, 9, 10, & 15 the data entries would be 01, 05, 09, 10, 15.

If you wanted to select all 32 you can press and hold the "9" button for 2 seconds to turn on all 32 options, if you wanted to turn them all off you can press and hold the "0" button for 2 seconds to turn them all off.

Deleting User codes, Account Codes, Telephone Numbers, etc

If a numeric entry such as user codes, monitoring account codes, telephone numbers, etc, needed to be deleted you can press and hold the <Control> button then press the <0> button (maintained for compatibility with the current ELITE S operation) or you can press and hold the <0> button for 3 seconds to delete the entry.

Programming LCD custom text

All LCD text is stored in the control panel memory and transferred to all keypads so the panel remains the master database at all times. If user text is changed (eg User Name, Area Name, Output Name, etc) the new text is broadcast to every LCD keypad on the bus as soon as the enter button is pressed to save the changes so all keypads have the new text immediately. If a new LCD keypad is added to the system the panel broadcasts the CRC's for all of the text blocks so the keypads can compare their CRC with the panels. If there is a difference in the CRC's indicating that the LCD and panel text don't match a request is made by the keypad to download all text blocks where the CRC's don't match ensuring all keypads stay up to date with the panel. This task is carried out in the back ground and does not have to be initiated by the installer or end user.

Key-switch Programming

The Key-switch function has now been moved to being a zone function. If any arm/disarm option is turned on at P120E the associated zone will now be a key-switch, eg P120E48E options 1 & 3 turned on would mean that zone 48 is now a key-switch that can arm and disarm the area/s assigned at P121E48E.

LCD Keypad Operational Mode

The full LCD keypad will always show "Areas Armed" as soon as any area associated with the keypad is armed. If option 4 is off at P96E for the associated keypad the "Areas Armed" will show one area at a time on the bottom line of the display. The full Area name will be shown. The area names will cycle through showing all currently armed areas. An armed area could be fully armed or stay armed. If some areas associated with the keypad are not armed the "Ready LED" will still turn off when zones are unsealed but they will not be displayed while "Areas Armed" is on. To see any unsealed (not Ready) zones you can press the "Enter" button to switch to the zone display menu. After 10 seconds of no button presses the display will revert back to the "Areas Armed" display. Alternatively if the "Down Arrow" button is pressed while the display is showing "Areas Armed" the display will change from showing the individual area names to area numbers. Up to 7 two digit area numbers can be displayed on the bottom line. If there are more than 7 areas armed the display will cycle through 7 area numbers at a time repeating the cycle once it has shown all areas. By repeatedly pressing the "Down Arrow" the user can control what areas are displayed on the bottom line. If the "Down Arrow" is not pressed for 15 seconds the display will revert back to normal. If option 4 is on at P96E for the associated keypad the "Areas Armed" will show up to 7 area numbers on the bottom line and will cycle through the list if more than 7 areas are armed. If the "Down Arrow" button is pressed the user can control what areas are displayed on the bottom line. If the "Down Arrow" is not pressed for 15 seconds the display will revert back to normal.

ECi BULK COPY FUNCTION

There are a number of program locations where selected program data can be copied to a range of similar program addresses. The list of these program locations is shown below. As an example if user 100 was set up as a template and users 101 to 200 were to all have the same program options, by entering in P17E 100E followed by 101E then 200E the panel will copy all of the programmed data for user 100 to users 101 to 200. This feature can be performed multiple times, eg user 250 could be set up as a template then it could be copied to users 251 to 300.

Bulk COPY a User to a range of Users

P17E Template User #E Start User #E End User #E Bulk COPY a User to a range of USERS

Bulk COPY an Output to a range of Outputs

P30E Template Output #E Start Output #E End Output #E Bulk COPY an Output to a range of OUTPUTS

Bulk COPY an Area to a range of Areas

P70E Template Area #E Start Area #E End Area #E Bulk COPY an Area to a range of AREAS

Bulk COPY a Keypad to a range of Keypads

P97E Template Keypad #E Start Keypad #E End Keypad #E Bulk COPY a Keypad to a range of KEYPADS

Bulk COPY a Zone to a range of Zones

P118E Template Zone #E Start Zone #E End Zone #E Bulk COPY a Zone to a range of ZONES

ECi LCD TEXT PROGRAM SUMMARY GUIDE

There are a number of program locations where custom text names can be programmed. These custom text names are used by the LCD keypad when displaying area names when armed and also when viewing events in memory mode.

P16E	1-2000E	Program LCD KP "User" Name Text	Program LCD KP "User" Name
P25E	14E	This location is where the LCD KP "Idle" Display Name can be Programmed.	LCD KP "Idle" Display Name
P31E	1-32E	Program LCD KP "Output" Name Text	Program LCD KP "Output" Name
P69E	1-32E	Program LCD KP "Area" Name Text	Program LCD KP "Area" Name
P100E	1-32E	Program LCD KP "Keypad" Name Text	Program LCD KP "Keypad" Name
P169E	1-64E	Program LCD KP "Zone" Name Text	Program LCD KP "Zone" Name

DTMF COMMAND CONTROL SEQUENCE

If DTMF Command Control has been enabled the operation is performed as follows.

Call the control panel.

When the panel answers it will play the message "Enter your code followed by the # key".

At that point enter in your DTMF Code (program location P63E for Area Arm/Disarm or P175E12E for Output control) followed by the # key on the phone.

DTMF Arming and Disarming

If for example the DTMF code to remotely arm and disarm Area 1 (P63E1E) was 1234 and Area 1 was disarmed, when you enter the Area 1 DTMF code;

1234 # - (you will hear the message "Area 1 Disarmed")

If you then press the * key it will change the state of Area 1, eg

* - (you will hear the message "Area 1 Armed")

DTMF Output Control

If for example the DTMF code to remotely control Outputs (P175E12E) was 9876 and you were controlling Output 1 (which was currently Off), when you enter the Output DTMF code followed by output 1 (01);

9876 01 # - (you will hear the message "Output 1 Off")

If you then press the * key it will change the state of Output 1, eg

* - (you will hear the message "Output 1 On")

Exiting DTMF Control Mode

When all DTMF remote control functions are completed you can either hang up the phone and the control panel will hang up automatically in 15 seconds or you can press;

00 # - (you will hear "Goodbye") and the panel will hang up immediately.

DISPLAY APP SERIAL #, IP & MAC ADDRESS AT KEYPAD

When the panel is in normal mode (ie not in program mode) it is possible to display via the EC-LCD the currently assigned IP address for the panel, the MAC address, and the app Serial number. There is a similar display function using the Service menu on an EC-TOUCH but it must have Version 8.05.220414 or later firmware.

To view the APP Serial Number

At the LCD keypad press and hold the <7> button for 4 seconds until the display shows the panels APP Serial number. To exit the display mode press the <ENTER> button.

To view the MAC Address

At the LCD keypad press and hold the <8> button for 4 seconds until the display shows the panels MAC address. To exit the display mode press the <ENTER> button.

To view the IP Address

At the LCD keypad press and hold the <9> button for 4 seconds until the display shows the panels IP address. To exit the display mode press the <ENTER> button.

DISPLAY CURRENT PATH To The INTERNET

When the panel is in normal mode (ie not in program mode) it is possible to display via the EC-LCD the current path the panel is using to connect to the internet. This function was released at firmware version 10.3.42.

To view the Current Internet Path

At the LCD keypad press and hold the <6> button for 4 seconds until the display shows the panels Internet path. The options are "Ethernet" or "4G". To exit the display mode press the <ENTER> button.

Automatic Control of Doors

When there is a need to unlock a controlled door during the day and keep it unlocked, this can be achieved two ways. The first is to program a Time Zone to the output (P44E), the second is to program the area disarm indication to the output (P49E).

Unlock on a Time Zone

Any of the 32 Time-zones can be assigned to outputs 1-32. This function can be used to unlock a controlled door so the door will remain unlocked while the T/Z is on and relock it when the T/Z is off allowing normal timed access control through the door when the T/Z is inactive. If a TZ has turned an Output ON the TZ will override any reset time programmed for the Output. A TZ can be linked to holidays (P174E option 1 Off) so that the TZ will not unlock the door when a holiday is active. The reset, pulse or chime timers can resume controlling the Output once the TZ has ended and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while the TZ is active (see additional comment below).

Unlock when Disarmed

Each Area can have a disarm indication assigned to an output to unlock a controlled door so the door will remain unlocked while the alarm is disarmed and relock it when the alarm is armed allowing normal timed access control through the door afterhours. This function allows a door to be unlocked only when the premises are occupied and relocked when the premises are vacated (ie the alarm is armed). If an Area Disarm has turned an Output ON this will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the Area is armed and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while disarmed (see additional comment below).

<CONTROL> override of an unlocked door

When an output is on because a TZ is active or the alarm is disarmed the output will stay on until the TZ is inactive or the alarm is armed.

At times there may be reasons why the door needs to be locked even if a TZ is active or the alarm is disarmed, (eg an employee is at work on a public holiday and the alarm is disarmed but they want the door to be locked).

Under these special conditions it is possible to program the output connected to the door so that it can be controlled using the <CONTROL> button at the keypad closest to the controlled door. At Program address P83E the output controlling the door can be assigned to a keypad close to the controlled door. By pressing the control button for 2 seconds (option 8 must be on at P96E to allow direct control of the output) the door control can be overridden. If the control button is pressed for another 2 seconds it will unlock the door again.

ECi PROGRAM SUMMARY GUIDE

+++++Users+++++

Programming User Codes

P1E 1-2000E User Code 1-2000 - Default for User Code # 1 (P1E1E) = 123 Codes can be 1-6 or 4-6 digits.
(where 1E = User Code #1 to 2000E = User Code #2000)

NOTE: The 2000 Users can be keypad Code, Radio or Access key Users. They can be mixed but the Maximum is 2000 Users.
The User type MUST be set to "0" (P2E User# E) for a code to be entered at the above address.

User Type (Code/Radio/Access Tag-Card)

P2E 1-2000E User # 1-2000 Type -
(Default = 0)

- 0 = Keypad Code User {PIN}
- 1 = Radio User (Users 101-2000 only)
- 2 = Access Tag/Card User
- 3 = Both Code and Access Tag/Card User (Tag + PIN)
- 4 = Either Code or Access Tag/Card User {Tag or PIN}

User Area Assignment

P3E 1-2000E User # 1-2000 Area -
(Default = 1)

01-32 = Assigned to Area 1-32

User Code Access Options

P4E 1-2000E Users 1-2000 Access Options
(Default = 1,3,4)

- 1 = Code can Arm Area
- 2 = Code can arm Stay Mode
- 3 = Code can Disarm Area
- 4 = Code can disarm Stay Mode
- 5 = Code is a Security Guard Code
- 6 = Code will Arm Latchkey Mode
- 7 = User can reset latched Egress Outputs
- 8 = Can View Event Memory

User Code Privileges

P5E 1-2000E Users 1-2000 Privileges
(Default User 1 = 2,3,4,5,6,7,8)
(Default User 2-2000 = All Off)

- 1 = User can Change their Code
- 2 = User can Change All Codes
- 3 = User can Allow Access to Installer Mode/Edit all Codes
- 4 = User can Change Telephone Numbers
- 5 = User can Change the Clock
- 6 = User can Change DTMF Command Codes
- 7 = User can Learn New Radio Devices
- 8 = Spare

User Code Misc Options

P6E 1-2000E Users 1-2000 Misc Opts

1 = User is excluded from Global trouble reset (P25E10E)

Radio User Type

P7E 101-2000E Radio User 101-2000 Type
(Default = 0)

- 0 = General Pendant Type
- 1 = Infinity Pendant
- 21 = Ness Pendant

Radio User Privileges

P8E 101-2000E Radio Users 101-2000 Privileges
(Default = 1)

- 1 = Pendant Can Disarm at All Times
- 2 = Pendant Causes Immediate Panic
- 3 = Pendant Causes Delayed Panic (1.5 Sec)
- 4 = Pendant only works during Entry Delay
- 5 = This User is a Duress Code (Users 101-2000)
- 6 = Spare
- 7 = Spare
- 8 = Spare

Schedule Assigned to a User

P9E 1-2000E Schedule to User # 1-2000
(Default = All Off)

- 01 = User Controlled by Schedule # 1
- 02 = User Controlled by Schedule # 2
- 03 = User Controlled by Schedule # 3
- 04 = User Controlled by Schedule # 4
- 05 = User Controlled by Schedule # 5
- 06 = User Controlled by Schedule # 6
- 07 = User Controlled by Schedule # 7
- 08 = User Controlled by Schedule # 8
- 32 = User Controlled by Schedule # 32

User Activates Dormant Schedule

P1032E 1-2000E User Activates Schedule # 1-2000
(Default = All Off)

- 01 = User Activates Schedule # 1
- 02 = User Activates Schedule # 2
- 03 = User Activates Schedule # 3
- 04 = User Activates Schedule # 4
- 05 = User Activates Schedule # 5
- 06 = User Activates Schedule # 6
- 07 = User Activates Schedule # 7
- 08 = User Activates Schedule # 8
- 32 = User Activates Schedule # 32

P1033E 1-2000E	Access Group for User # 1-2000 (Default = 0)	Access Group for User 1-2000 Value = Access group 1-32
P10E 1-2000E	User # 1-2000 Keypad Assignment (Default = All On)	User to Keypad Assignment 01 = Can Operate at Keypad # 1 02 = Can Operate at Keypad # 2 03 = Can Operate at Keypad # 3 04 = Can Operate at Keypad # 4 05 = Can Operate at Keypad # 5 06 = Can Operate at Keypad # 6 07 = Can Operate at Keypad # 7 08 = Can Operate at Keypad # 8 a 32 = Can Operate at Keypad # 32
P11E 101-2000E	Radio # 101-2000 Panic Beep to Keypad (Default = All On)	Radio Pendant Panic Beeps to Keypad 01 = A Radio panic will Beep at Keypad # 1 02 = A Radio panic will Beep at Keypad # 2 03 = A Radio panic will Beep at Keypad # 3 04 = A Radio panic will Beep at Keypad # 4 05 = A Radio panic will Beep at Keypad # 5 06 = A Radio panic will Beep at Keypad # 6 07 = A Radio panic will Beep at Keypad # 7 08 = A Radio panic will Beep at Keypad # 8 a 32 = A Radio panic will Beep at Keypad # 32
P13E 1-2000E	User # 1-2000 Can Turn On an Output (Default = All Off)	User can Turn an Output On 01 = User Can Turn on Output # 1 02 = User Can Turn on Output # 2 03 = User Can Turn on Output # 3 04 = User Can Turn on Output # 4 05 = User Can Turn on Output # 5 06 = User Can Turn on Output # 6 07 = User Can Turn on Output # 7 08 = User Can Turn on Output # 8 a 32 = User Can Turn on Output # 32
P14E 1-2000E	User # 1-2000 Can Turn Off an Output (Default = All Off)	User can Turn an Output Off 01 = User Can Turn off Output # 1 02 = User Can Turn off Output # 2 03 = User Can Turn off Output # 3 04 = User Can Turn off Output # 4 05 = User Can Turn off Output # 5 06 = User Can Turn off Output # 6 07 = User Can Turn off Output # 7 08 = User Can Turn off Output # 8 a 32 = User Can Turn off Output # 32
P15E 101-2000E	Radio # 101-2000 Panic Alarm to an O/P (Default = 1,2)	Radio Pendant Panic Alarm to an Output 01 = Radio panic to Output # 1 02 = Radio panic to Output # 2 03 = Radio panic to Output # 3 04 = Radio panic to Output # 4 05 = Radio panic to Output # 5 06 = Radio panic to Output # 6 07 = Radio panic to Output # 7 08 = Radio panic to Output # 8 a 32 = Radio panic to Output # 32
P16E 1-2000E	Program LCD KP "User" Name Text	Program LCD KP "User" Name
P17E	Template User #E Start User #E End User #E	Bulk COPY a User to a range of Users Bulk COPY a User to a range of USERS
P18E 101-2000E	Learn Radio Pendant Codes for Users 101-2000 (applies if the User Type, P2E, is set to 1)	Learn Radio Pendant Codes
P19E 101-2000E	Delete a Specific Radio Pendant Code for Users 101-2000 (applies if the User Type, P2E, is set to 1)	Delete a Specific Radio Pendant Code
P20E ENTER	Enter this address then operate the Radio Pendant to find its user # (applies if the User Type, P2E, is set to 1). After P20E press enter to start the find process.	Find Radio Pendant memory Location
P21E 1-2000E	Learn Access Tag/Card Codes for Users 1-2000 (applies if the User Type, P2E, is set to 2, 3 or 4)	Learn Access Tag/Card Codes

Delete a Specific Access Tag/Card Code		
P22E	1-2000E	Delete a Specific Access Tag/Card Code for Users 1-2000 (applies if the User Type, P2E, is set to 2, 3 or 4)
Find an Access Tag/Card memory Location		
P23E		Enter this address then operate the Access Tag/Card to find its user # (applies if the User Type, P2E, is set to 2, 3 or 4). After P23E press enter to start the find process.
Manually enter in a Card/Tag Printed Number		
P24E	1-2000E	Enter this address then type in the 10 digit printed card/tag number #
Code/Tag/Radio User Usage Count		
P1025E	1-2000E	A value of 1-254 equals the number of times it can be used. 255 = always.
Code/Tag/Radio User Start Date		
P1026E	1-2000E	DD:MM:YY The date a Code/Tag/Radio User will start to function.
Code/Tag/Radio User End Date		
P1027E	1-2000E	DD:MM:YY The date a Code/Tag/Radio User will cease to function.
Code/Tag/Radio User Start Time		
P1028E	1-2000E	HH:MM The time a Code/Tag/Radio User will start to function.
Code/Tag/Radio User End Time		
P1029E	1-2000E	HH:MM The time a Code/Tag/Radio User will cease to function.

+++++Miscellaneous Panel & Clock Settings+++++

Installer Code		
P25E	1E	Installer Code - (Default = 000000)
Duress Digit		
P25E	2E	Duress Digit - Value 1-9 (Default = 0 Duress Function Disabled)
Dial Report Delay		
P25E	3E	Dial Report Delay - Value 0-255 seconds (Default = 0)
Radio Detector Supervised Timer		
P25E	4E	Radio Detector Supervised Timer - 0-9999 Minutes (Default = 240 Minutes [4 Hours])
Two Trigger Timer		
P25E	5E	Two Trigger Timer - Value 0-255 Seconds (Default = 60 Sec)
Mains Fail Reporting Delay		
P25E	6E	Mains Fail Reporting Delay - Value 0-9999 Seconds (Default = 600 Sec)
Receiver Fail Delay		
P25E	7E	Receiver Fail Delay - Value 0-9999 Seconds (Default = 0 Sec-Disabled)
Upload/Download Site Code Number		
P25E	8E	Upload/Download Site Code Number - Up to 8 Characters (Default = None)
Temporary Output Disable		
P25E	9E	Temporary Output Disable - Output 1-32
Miscellaneous Panel Options		
P25E	10E	Misc. Panel Options (Default = 2,6) Miscellaneous Options 1 = Panel Tamper is 2k2 EOL 2 = Direct access to program mode for the installer code. 3 = Disable Mains Fail Test 4 = Globally reset trouble alarms 5 = Cannot arm the alarm if Receiver fail mode is active 6 = Enable iPSU AC and Battery Low monitoring 7 = Cannot arm if the system battery is low 8 = Installer Lockout
Installer Options		
P25E	11E	Installer Options (Default = All Off) 1 = Installer <u>MUST</u> enter program mode via Client mode to reset confirmed alarms 2 = Installer <u>MUST</u> enter program mode via Client mode to reset tamper alarms 3 = Installer <u>MUST</u> enter program mode via Client mode to reset low battery alarms 4 = Installer <u>MUST</u> enter program mode via Client mode to reset supervisory alarms 5 = Cannot Arm if there is a keypad Fault 6 = Cannot Arm if there is a Telephone Line Failure or Comms Fault 7 = 10 Incorrect Code Attempts locks out the keypad for 90 Seconds 8 = User Codes Must be 4-6 digits long
User Options		
P25E	12E	User Options (NOTE: This Option can ONLY be accessed from Client Mode) (Default = All Off)
P25E	13E	Misc. User Options (Default = None) Miscellaneous User Options 1 = Hide User Codes from Installer 2 = Cancel Handover Zone Function in Stay Mode

- 3 = Output Control from Keypad is Disabled when Armed
- 4 = Keypad Codes are Disabled During Entry Delay
- 5 = Keypad LED's and Backlight off on no activity
- 6 = Use new multi-area arming method
- 7 = Enable Keypad Tamper Switch Alarms
- 8 = Spare

LCD KP "Idle" Display Name

P25E 14E This location is where the LCD KP "Idle" Display Name can be Programmed.

Webpage "Incorrect Login" Count

P25E 15E 0-255. If this address is set to 0 there is no incorrect login count. If set from 1-255, that is the number of incorrect login attempts before the webpage access is locked out.

Webpage "Incorrect Login" Lockout Time

P25E 16E 0-9999. If this address is set to 0 there is no lockout time if the programmed count at P25E15E is exceeded. If set from 1-9999, that is the time in seconds that all webpage access will be locked out for.

World Time Zone

P25E 17E World Time Zone

Program Mode/Arming Options

P25E 18E Prog/Arm Options
(Default = None)

Program Mode/Arming Options

- 1 = Can enter program mode when another area is armed
- 2 = Can arm when a keypad in a different area is in program mode
- 3 = Serial over IP Authentication Required
- 4 = Disable Tamper to Output when disarmed
- 8 = Hide extended information in the memory events

Serial over IP User Name

P25E 19E Serial over IP User Name (maximum 16 characters)

Serial over IP Password

P25E 20E Serial over IP Password (maximum 16 characters)

Serial over IP User Timeout

P25E 21E Serial over IP User Timeout (Default = 300, 10-600 seconds)

KP Bus Device Alarms

P25E 22E KP Bus Device Alarms
(Default = None)

KP Bus Device Alarm Options

- 1 = Disable Zone Expander missing and tamper Alarms
- 2 = Disable Output Expander missing and tamper Alarms
- 3 = Disable Access board IF-2 missing and tamper Alarms

LCD Keypad Language Selection

P25E 23E LCD KP Languages

LCD Keypad language Selection

(NOTE: Use left/right arrow keys to select)
(Default = English)

- 1 = English
- 2 = Turkish
- 3 = Romanian
- 4 = Greek

Setting Real Time Clock

P26E 1E Real Time Hour/Minute - Value 0-2359

P26E 2E Real Time Day of Week - Value 1-7 (1=Sunday, 2=Monday ,etc)

P26E 3E Real Time Date/Month/Year - Value DDMMYY (eg 020904 = 2nd Sept 2004)

P26E 4E Daylight Saving is Active (If LED #1 is On, Daylight Saving is currently active) Turn this bit ON if you are in Daylight Saving Time when the panel is installed.

NOTE: If option 3 at P201E4E is turned on (panel clock synced to the internet time) the above time and date settings cannot be altered.

Daylight Saving settings

P27E 1E Daylight Saving Start Sunday - Value 0-5 - Default = 5 (0 = DLS disabled, 5 = last Sunday of Month)

2E Daylight Saving End Sunday - Value 0-5 - Default = 1 (0 = DLS disabled, 5 = last Sunday of Month)

P28E 1E Daylight Saving Start Month - Value 1-12 - Default = 9 (0 = DLS disabled)

2E Daylight Saving End Month - Value 1-12 - Default = 4 (0 = DLS disabled)

P29E 1E Daylight Saving Start Hour - Value 0-23 - Default = 2

2E Daylight Saving End Hour - Value 0-23 - Default = 3

+++++Outputs+++++

Bulk COPY an Output to a range of Outputs

P30E **Template O/P #E Start O/P #E End O/P #E** **Bulk COPY an Output to a range of OUTPUTS**

Program LCD KP "Output" Name

P31E **1-32E** **Program LCD KP "Output" Name Text**

Program Output Volume when Disarmed

P33E **1-2E** **The Volume of O/P 1 & 2 when the alarm is disarmed can be set to a value of 1-8**

Program Access Groups

P3101E	1-32E	Output #1 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3102E	1-32E	Output #2 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3103E	1-32E	Output #3 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3104E	1-32E	Output #4 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3105E	1-32E	Output #5 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3106E	1-32E	Output #6 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3107E	1-32E	Output #7 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3108E	1-32E	Output #8 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3109E	1-32E	Output #9 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3110E	1-32E	Output #10 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3111E	1-32E	Output #11 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3112E	1-32E	Output #12 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3113E	1-32E	Output #13 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3114E	1-32E	Output #14 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3115E	1-32E	Output #15 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3116E	1-32E	Output #16 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3117E	1-32E	Output #17 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3118E	1-32E	Output #18 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3119E	1-32E	Output #19 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3120E	1-32E	Output #20 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3121E	1-32E	Output #21 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3122E	1-32E	Output #22 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3123E	1-32E	Output #23 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3124E	1-32E	Output #24 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3125E	1-32E	Output #25 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3126E	1-32E	Output #26 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3127E	1-32E	Output #27 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3128E	1-32E	Output #28 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3129E	1-32E	Output #29 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3130E	1-32E	Output #30 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3131E	1-32E	Output #31 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7
P3132E	1-32E	Output #32 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7

Programming Output Options "A"

P34E	1-32E	Options "A" for Outputs 1-32 (Default = All Off) <ul style="list-style-type: none"> 1 = Invert Output 2 = Flash Output 3 = Single Pulse to Output 4 = Lockout Output 5 = DTMF Remote Control can operate Output 6 = User Can operate this Output 7 = "Control" button Can Operate Output 8 = Chime Alarms will Flash this Output (linked to Pulse Timer)
-------------	--------------	--

Programming Output Options "B"

P35E	1-32E	Options "B" for Outputs 1-32 (Default O/P's 1&2 = 7) (Default O/P's 3-8 = All Off) <ul style="list-style-type: none"> 1 = Mains Fail to Output (Operates when P25E6E time expires) 2 = Fuse Failure to Output 3 = Battery Low to output 4 = Telephone Line Failure to Output 5 = Supervised Radio Signal Failure 6 = Sensor-Watch Alarm 7 = System Tamper to Output 8 = Receiver Fail
-------------	--------------	--

Programming Output Options "C"

P36E	1-32E	Options "C" for Outputs 1-32 (Default = All Off) <ul style="list-style-type: none"> 1 = Walk Test Pulse to Output 2 = Pulse Output every 5 seconds when Disarmed 3 = Pulse Output on Kiss-off Following Arming 4 = Pulse Output on Kiss-off Following a Zone Alarm 5 = Output Disabled when P25E3E timer is running 6 = Output indicates In-coming phone call. 7 = Play Doorbell tone on a Chime zone trigger 8 = IP Fail (Timed)
-------------	--------------	---

Programming Output Options "D"

P37E	1-32E	Options "D" for Outputs 1-32 (Default = All Off)	1 = Siren Driver to Output (requires a horn speaker, outputs 1&2) 2 = Output Chime timer is in minutes (off for 1/10th sec) 3 = Output 'silenced' for 10 seconds on key-press if alarm 4 = Turn Output OFF during Two Way Voice Mode 5 = Spare 6 = Pulse output when exit delay to Output (P65E) is running 7 = Output follows "Global Fire Egress Zone" 8 = Monitored Output (can tell if siren cable is cut, outputs 1&2 only)
-------------	--------------	---	---

Output ON Delay Time

P38E	1-32E	Output 1-32 ON Delay Time - 0-9999 Seconds (Default = 0 Sec)
-------------	--------------	---

Output Pulse Time

P39E	1-32E	Output 1-32 Pulse Time - 0-255;1/10th Sec increments (Default =2 which is 0.2 sec)
-------------	--------------	---

Output Reset Time

P40E	1-32E	Output 1-32 Reset Time - 0-65535 Seconds (Default = 300 Sec)
-------------	--------------	---

Output Chime Mode Time

P41E	1-32E	Output 1-32 Chime Timer - 0-9999;1/10th Sec increments (Default =10 which is 1 sec)
-------------	--------------	--

IP Fail Re-Trigger Timer

P42E	1-32E	IP Fail Re-Trigger Timer - 0-9999 Seconds
-------------	--------------	--

Un-Map an Output

P43E	1-32E	Un-map Outputs 1-32 (remove ALL Defaults from an Output)
-------------	--------------	---

Assigning a Schedule to an Output

P44E	1-32E	Schedules that will control Outputs 1-32 - Value = Schedule 01-32 (Default = All Off) (NOTE: If a Schedule has turned an Output ON the Schedule will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the Schedule has ended and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while the Schedule is active.)
-------------	--------------	--

Assign INFINITY OUTPUT to ECi Output

P99E	1-32E	Assign Output 1-32 to INFINITY Output
-------------	--------------	--

+++++Areas+++++

Area 1-32 Options A

P45E	1-32E	Area 1-32 Options A (Default = All Off)	1 = Arm Button Required Before Code to Set 2 = Stay Button Required Before Code to Set Stay Mode 3 = Code required to Set 4 = Code Required to Bypass Zones 5 = Spare 6 = Send Arm at the end of the Exit Delay 7 = Can Arm only if All Zones are Sealed (Ready) 8 = Can Arm Stay Mode only if All Zones are Sealed (Ready)
-------------	--------------	--	--

Area 1-32 Options B

P46E	1-32E	Area 1-32 Options B (Default = All Off)	1 = Near and Confirmed Alarm reporting for All zones in this Area (CID only) 2 = Area will arm at end of schedule 3 = Area will disarm at beginning of schedule 4 = Assign Chirps to Access tags 5 = Spare 6 = Inhibit Arming if zone unsealed while Exit Delay is Active. 7 = Cannot Arm if Zone Unsealed at end of Exit Delay 8 = Arm on no Activity
-------------	--------------	--	---

Area 1-32 Arm Indication to Output

P47E	1-32E	Area 1-32 Arm Indication to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
-------------	--------------	---

Area 1-32 Stay Arm Indication to Output

P48E	1-32E	Area 1-32 Stay Arm Indication to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
-------------	--------------	--

Area 1-32 Disarm Indication to Output

P49E	1-32E	Area 1-32 Disarm Indication to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
-------------	--------------	--

(NOTE: If an Area Disarm has turned an Output ON this will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the Area is armed and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while disarmed.)

Area 1-32 Pendant (or Access Tag) Arm Chirp to Output

P50E	1-32E	Area 1-32 Arm Chirp to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)	(One chirp to the output for arm)
-------------	--------------	--	--

Area 1-32 Pendant (or Access Tag) Stay Arm Chirp to Output

P51E	1-32E	Area 1-32 Stay Arm Chirp to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)	(One chirp to the output for stay arm)
-------------	--------------	---	---

Area 1-32 Pendant (or Access Tag) Disarm Chirp to Output		
P52E	1-32E	Area 1-32 Disarm Chirp to Output - Value 01-32 (for Outputs 1-32) (Default = All Off) (Two chirps to the output for disarm)
Area 1-32 Pendant Stay (or Access Tag) Disarm Chirp to Output		
P53E	1-32E	Area 1-32 Stay Disarm Chirp to Output - Value 01-32 (for Outputs 1-32) (Default = All Off) (Two chirps to the output for disarm)
Area 1-32 Arm Pulse to Output		
P54E	1-32E	Area 1-32 Arm Pulse to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Stay Arm Pulse to Output		
P55E	1-32E	Area 1-32 Stay Arm Pulse to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Disarm Pulse to Output		
P56E	1-32E	Area 1-32 Disarm Pulse to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Stay Disarm Pulse to Output		
P57E	1-32E	Area 1-32 Stay Disarm Pulse to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Armed Mode Exit Delay Beeps to Keypad		
P58E	1-32E	Area 1-32 Armed Exit Delay Beeps to Keypad - Value 01-32 (for Keypads 1-32) (Default, Area 1 = All On, Areas 2-32 = All Off)
Area 1-32 Stay Mode Exit Delay Beeps to Keypad		
P59E	1-32E	Area 1-32 Stay Exit Delay Beeps to Keypad - Value 01-32 (for Keypads 1-32) (Default Area 1 = All On, Areas 2-32 = All Off)
Area 1-32 Armed Exit Delay Time		
P60E	1-32E	Area 1-32 Exit Delay Time - Value 0-255 seconds (Default = 30 Seconds for all Areas)
Area 1-32 Stay Armed Exit Delay Time		
P61E	1-32E	Area 1-32 Stay Exit Delay Time - Value 0-255 seconds (Default = 30 Seconds for all Areas)
Area 1-32 Monitoring Account Code Number		
P62E	1-32E	Area 1-32 Account Code - Value 0000-FFFF (Default = 0000 for all Areas)
Area 1-32 Remote "Command Control" Code Number		
P63E	1-32E	Area 1-32 Command Control code - Value 1-4 digit code (1-9999) (Default = No code for all Areas)
Start Message Number for Areas 1-32 "Command Control"		
P64E	1-32E	Reserved for future use.
Area 1-32 Armed Mode Exit Delay to Output		
P65E	1-32E	Area 1-32 Armed Exit Delay to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Stay Mode Exit Delay to Output		
P66E	1-32E	Area 1-32 Stay Exit Delay to Output - Value 01-32 (for Outputs 1-32) (Default = All Off)
Area 1-32 Delinquency Delay		
P67E	1-32E	Area 1-32 Delinquency Delay - value 0-99 Days, (0 = Off) (Default = 0 for all Areas)
Area 1-32 Auto Arm/Disarm Schedules		
P68E	1-32E	Area 1-32 Auto Arm/Disarm Schedules - Value 01-32 (for Schedules 1-32) (Default = All Off)
Program LCD KP "Area" Name		
P69E	1-32E	Program LCD KP "Area" Name Text
Bulk COPY an Area to a range of Areas		
P70E	Template Area #E Start Area #E End Area #E Bulk COPY an Area to a range of AREAS	
Area 1-32 Zone Activity Timer		
P4071E	1-32E	Area 1-32 Zone Activity Timer - Value 0-255 Minutes (Default = 0)
Area 1-32 Arming Pre-alert Timer		
P4072E	1-32E	Area 1-32 Arming Pre-alert Timer - Value 0-255 Seconds (Default = 0)
Area 1-32 Disarm Delay Timer		
P4073E	1-32E	Area 1-32 Disarm Delay Timer - Value 0-9999 Seconds (Default = 0)

Area 1-32 "In Alarm" Disarm Delay Timer

P4074E 1-32E **Area "In Alarm" Disarm Delay Timer** - Value 0-9999 Seconds
(Default = 0)

Zones Associated with Areas 1-32

P4075E 1-32E **This is a display only address that shows all Zones associated with the selected Area**

Active Areas

P4076E 1E **This is a display only address that shows all Areas with Zones assigned to them**

+++++Keypads+++++

Keypad Area Assignment

P71E 1-32E **Keypads Assigned To Areas** 01-32 = Areas 1-32
(Default = 1,2)

Keypad Button Options

P72E 1-32E **Keypad Button Options**
(Default = All 1,2)

(NOTE: Options 5, 6 & 7 create a separate alarm for every area assigned to the keypad at P71E. To clear all alarms the User MUST have the same areas set at P3E)

- 1 = <CHIME> Button Enabled
- 2 = <BYPASS> Button Enabled
- 3 = Code or Tag can ARM only at this keypad
- 4 = Code or Tag can STAY ARM only at this keypad
- 5 = <1> + <3> or <CONTROL> + <CHIME> Panic Alarm Enabled
- 6 = <4> + <6> or <A> + Fire Alarm Enabled
- 7 = <7> + <9> or + <CHIME> Medical Alarm Enabled
- 8 = Stay Armed Beep to Keypad

Keypad Options C

P5070E 1-32E **Keypad Options C**
(Default = All 1,2)

- 1 = Enable Away Disarm at Keypad
- 2 = Enable Stay Disarm at Keypad
- 3 = Keypad FIRE alarm pulses alarm output

Alarm Beeps to Keypad

P73E 1-32E **Keypad Beep Options**
(Default = 5)

- 1 = Mains Fail Beeps Keypad Buzzer
- 2 = Fuse Failure Beeps Keypad Buzzer
- 3 = Battery Low Beeps Keypad Buzzer
- 4 = Telephone Line Failure Beeps Keypad Buzzer
- 5 = System Tamper Alarm Beeps Keypad Buzzer
- 6 = Receiver Fail Beeps Keypad Buzzer
- 7 = Turn Off Keypad LED's and Backlighting when Armed
- 8 = Turn Off LCD & Keypad & Backlighting on Mains Failure

Keypad "ARM" Button Area Assignment

P74E 1-32E **Keypad "ARM" Button Area** 01-32 = "ARM" Button assigned to Area 1-32
(Default = 1)

Keypad "ARM" Button Area Options

P75E 1-32E **Keypad "ARM" Button Opts.**
(Default = 1,7)

- 1 = "ARM" Button can Arm
- 2 = "ARM" Button can Stay Mode Arm
- 3 = "ARM" Button can Disarm at All Times
- 4 = "ARM" Button can Disarm Stay Mode at All Times
- 5 = "ARM" Button can Reset Alarms
- 6 = "ARM" Button can Arm Latchkey Mode
- 7 = "ARM" Button can Disarm During Exit Delay
- 8 = "ARM" Button can Disarm Stay Mode During Exit Delay

Keypad "STAY" Button Area Assignment

P76E 1-32E **Keypad "STAY" Button Area** 01-32 = "STAY" Button assigned to Area 1-32
(Default = 1)

Keypad "STAY" Button Area Options

P77E 1-32E **Keypad "STAY" Button Opts.**
(Default K/P 1,2,3,4,6,7,8 = 2,8)
(Default K/P 5 = 2,4)

- 1 = "STAY" Button can Arm
- 2 = "STAY" Button can Stay Mode Arm
- 3 = "STAY" Button can Disarm at All Times
- 4 = "STAY" Button can Disarm Stay Mode at All Times
- 5 = "STAY" Button can Reset Alarms
- 6 = "STAY" Button can Arm Latchkey Mode
- 7 = "STAY" Button can Disarm During Exit Delay
- 8 = "STAY" Button can Disarm Stay Mode During Exit Delay

Keypad "A" Button Area Assignment

P78E 1-32E **Keypad "A" Button Area** 01-32 = "A" Button assigned to Area 1-32
(Default = 1)

Keypad "A" Button Area Options

P79E 1-32E **Keypad "A" Button Opts.**
(Default = 1,7)

- 1 = "A" Button can Arm
- 2 = "A" Button can Stay Mode Arm
- 3 = "A" Button can Disarm at All Times
- 4 = "A" Button can Disarm Stay Mode at All Times
- 5 = "A" Button can Reset Alarms
- 6 = "A" Button can Arm Latchkey Mode
- 7 = "A" Button can Disarm During Exit Delay
- 8 = "A" Button can Disarm Stay Mode During Exit Delay

Keypad "B" Button Area Assignment

P80E 1-32E **Keypad "B" Button Area** 01-32 = "B" Button assigned to Area 1-32

(Default = 2)

Keypad "B" Button Area Options

P81E	1-32E	Keypad "B" Button Opts. (Default = All Off)	1 = "B" Button can Arm 2 = "B" Button can Stay Mode Arm 3 = "B" Button can Disarm at All Times 4 = "B" Button can Disarm Stay Mode at All Times 5 = "B" Button can Reset Alarms 6 = "B" Button can Arm Latchkey Mode 7 = "B" Button can Disarm During Exit Delay 8 = "B" Button can Disarm Stay Mode During Exit Delay
-------------	--------------	---	---

Keypad to Output Mask (for Access Control)

P82E	1-32E	Keypad to Output Mask (Default = All Off)	01-32 = The Keypad is linked to Output # 1-32
-------------	--------------	---	---

"Control" Button to Output Mask (for Access Control)

P83E	1-32E	Keypad "Control" Button to Output Mask (Default = All Off)	01-32 = The Keypad "Control" Button is linked to Output # 1-32
-------------	--------------	--	--

"Control" + "Chime" Panic Alarm to Outputs

P84E	1-32E	Keypad "Control" + "Chime" Panic Alarm to Outputs (Default = 1,2)	01-32 = The Keypad "Control" + "Chime" Panic Alarm will turn on Output # 1-32
-------------	--------------	---	---

"A" + "B" Fire Alarm to Outputs

P85E	1-32E	Keypad "A" + "B" Fire Alarm to Outputs (Default = 1,2)	01-32 = The Keypad "A" + "B" Fire Alarm will turn on Output # 1-32
-------------	--------------	--	--

"B" + "Chime" Medical Alarm to Outputs

P86E	1-32E	Keypad "B" + "Chime" Medical Alarm to Outputs (Default = 1,2)	01-32 = The Keypad "B" + "Chime" Medical Alarm will turn on Output # 1-32
-------------	--------------	---	---

"Duress" Alarm to Outputs

P87E	1-32E	Keypad "Duress" Alarm to Outputs (Default = All Off)	01-32 = The Keypad "Duress" Alarm will turn on Output # 1-32
-------------	--------------	--	--

Keypad "Tamper Switch" Alarm to Outputs

P88E	1-32E	Keypad "Tamper Switch" Alarm to Outputs (Default = All Off)	01-32 = The Keypad "Tamper Switch" Alarm will turn on Output # 1-32
-------------	--------------	---	---

Keypad "Wrong Code" Alarm to Outputs

P89E	1-32E	Keypad "Wrong Code" Alarm to Outputs (Default = All Off)	01-32 = The Keypad "Wrong Code" Alarm will turn on Output # 1-32
-------------	--------------	--	--

Manually Operated Panic Alarm Beeps to Keypads

P90E	1-32E	Panic Alarm Beeps to Keypads (Default = All On)	01-32 = A Panic Alarm at the selected keypad will Beep KP # 1-32
-------------	--------------	---	--

Manually Operated Fire Alarm Beeps to Keypads

P91E	1-32E	Fire Alarm Beeps to Keypads (Default = All On)	01-32 = A Fire Alarm at the selected keypad will Beep KP # 1-32
-------------	--------------	--	---

Manually Operated Medical Alarm Beeps to Keypads

P92E	1-32E	Medical Alarm Beeps to Keypads (Default = All On)	01-32 = A Medical Alarm at the selected keypad will Beep KP # 1-32
-------------	--------------	---	--

Wrong Code or Keypad Tamper Switch Alarm Beeps to Keypads

P93E	1-32E	Wrong Code or Keypad Tamper Switch Alarm Beeps to Keypads (Default = All On)	01-32 = Wrong Code or KP Tamper at Keypad 1-32 will Beep KP # 1-32
-------------	--------------	--	--

Chime Alarm Beep Time at a Keypad

P94E	1-32E	The Time the Chime Alarm will sound at Each Keypad - Value = 0-255 1/10th sec (Default = 20 which is 2 Seconds)	
-------------	--------------	---	--

LCD Keypad Back-light settings

P95E	1-32E	LCD Keypad Back-light Setting	0-100 = LCD B/L value 0-100%
-------------	--------------	--------------------------------------	------------------------------

Full LCD Keypad Display Options

P96E	1-32E	Full LCD Keypad Display Options (Default = All Off)	1 = 2 x 20 Display Mode (On=AAP Logo Display) 2 = Show 4G Signal Strength on EC-LCD display 3 = Show LCD System name (ON=Show KP Name, 1=OFF) 4 = Display Armed Areas as numbers 5 = Allow Control Button to Override Schedules 6 = Allow CONTROL of Outputs when Armed 7 = Double badge to ARM keypad 8 = Control button operates assigned outputs directly
-------------	--------------	---	---

Bulk COPY a Keypad to a range of Keypads

P97E	Template KP #E Start KP #E End KP #E	Bulk COPY a Keypad to a range of KEYPADS	
-------------	---	---	--

Proximity Reader LED to Output Mapping

P98E	1-32E	Proximity Reader LED to Output Mapping (Default = None)	01-32 = Proximity Reader 1-32 LED will follow the state of Output # 1-32
-------------	--------------	---	--

P99E	1-32E	Assign Output 1-32 to INFINITY Output	Assign INFINITY OUTPUT to ECi Output
P100E	1-32E	Program LCD KP "Keypad" Name Text	Program LCD KP "Keypad" Name
++++++Zones++++++			
P118E	Template Zone #E	Start Zone #E End Zone #E	Bulk COPY a Zone to a range of Zones
P119E	1E	Global EOL Zone Options (Default = 3)	Global EOL Zone Options 0 = If set to 0 allows P125E to set individual values from 1-13
		1 = 1k 2 = 1k5 3 = 2k2 4 = 3k3 5 = 3k9 6 = 4k7 7 = 5k6 8 = 6k8 9 = 10k 10 = 12k 11 = 22k 12 = 2k2 / 4k7 (Single Zone with tamper, Series combination) 13 = 3k3 / 6k8 (Single Zone with tamper, Series combination) 14 = 2k2 / 4k7 / 8k2 (Zone doubling with tamper, Series combination) 15 = 4k7 / 8k2 (Zone doubling no tamper, Series combination) 16 = 4k7 / 8k2 (Zone doubling no tamper, Parallel combination) 17 = 5k6 / 5k6 (Single Input with tamper, Series combination) 18 = 2k2 / 6k8 (Single Input with tamper, Series combination) 19 = 10k / 10k (Single Input with tamper, Series combination)	
P120E	1-248E	Zone Key-switch Operational Options (Default = All Off)	Zone Key-switch Operational Options
		(NOTE: K/S operation linked to Users 1-64 settings P1025E - P1029E, see full manual for details)	1 = K/S can Arm Area 2 = K/S can arm Stay Mode 3 = K/S can Disarm Area 4 = K/S can disarm Stay Mode 5 = K/S has Security Guard Options 6 = K/S will Arm Latchkey Mode 7 = Key-switch is N/O (If turned off the K/S is N/C) 8 = Key-switch is Momentary (If turned off the K/S is Latching)
P121E	1-248E	Assigning Zones to Areas 1-32 (Default = 1)	Programming Zones to Areas 01-32 = Assigned to Area 1-32
P122E	1-248E	Programming Zone Options A (Default Zone 1-4 = 1,6,7,8) (Default Zone 5-8 = 1,7,8) (Default Zone 9-16 = 7,8)	Programming Zone Options A
			1 = Zone is Active 2 = Zone is N/O (Off = N/C) 3 = Not an Exit Delay Zone 4 = Keypad Zone 5 = Zone is a Radio Zone 6 = Zone is a Stay Mode Zone 7 = Zone can be Manually Bypassed 8 = Zone can be Auto-Bypassed
P123E	1-248E	Programming Zone Options B (Default = All Off)	Programming Zone Options B
			1 = Zone is a Handover Zone 2 = Zone is a Two Trigger Zone 3 = Zone is a 24 Hour Zone 4 = Auto-reset Zone 5 = Zone is a 24 Hour Fire Zone 6 = Zone is shared (Off = not shared) 7 = Zone is a Chime Zone 8 = Zone is a Permanent Chime Zone
P124E	1-248E	Programming Zone Options C (Default = 2)	Programming Zone Options C
			1 = Can Arm if Zone is not Ready 2 = Will Send Multiple Reports via Dialler 3 = Sensor-Watch Zone 4 = Zone is on Soak Test 5 = Report using the highest assigned Area 6 = Zone will Not Report 24 hour Alarms via Dialler 7 = Pulse Output on Kiss-off Following an alarm 8 = Exit Terminator
P6133E	1-248E	Programming Zone Options D (Default = All Off)	Programming Zone Options D
			1 = Zone is Excluded from Activity monitoring 2 = Zone will hold off Arming until Sealed 3 = "Security Interlock" zone
P125E	1-248E	Programming Zone EOL Options (Default = 3)	Programming Zone EOL (End-of-line) Options
			0 = Short Circuit 1 = 1k

(NOTE: P119E MUST be set to 0 for P125E to work)

2 = 1k5
3 = 2k2
4 = 3k3
5 = 3k9
6 = 4k7
7 = 5k6
8 = 6k8
9 = 10k
10 = 12k
11 = 22k
12 = 2k2 / 4k7 (Single Input with tamper)
13 = 3k3 / 6k8 (Single Input with tamper)
17 = 5k6 / 5k6 (Single Input with tamper)
18 = 2k2 / 6k8 (Single Input with tamper)
19 = 10k / 10k (Single Input with tamper)

Programming Zone Response

P126E 1-248E Programming Zone Response
(Default = 9)

1 to 8 Vibration mode
(Zone EOL-P125E, for Vibration Mode MUST be type 3 only)
1 = highest and 8 is lowest sensitivity level.
9 to 26 Normal zone mode
Response time = approx 200ms –1sec

Programming the Radio Zone Detector Type

P127E 1-248E Programming the Radio Zone Type from the List - Value = 0-89
(Default = 4)

0 = Generic
3 = Infinity (supervised signal active)
4 = Infinity (non-supervised) - INCLUDES REMOTE/PANIC

Armed Zone Alarms to Outputs

P128E 1-248E Armed Zone Alarms to Output
(Default = 1,2)

01-32 = A Zone Alarm will Turn On Output # 1-32

Armed Stay Mode Zone Alarms to Outputs

P129E 1-248E Armed Stay Mode Zone Alarms to Output
(Default = 2)

01-32 = A Stay Mode Zone Alarm will Turn On Output # 1-32

24 Hour Zone Alarms to Outputs

P130E 1-248E 24 Hour Zone Alarms to Output
(Default = All Off)

01-32 = A 24 Hour Zone Alarm will Turn On Output # 1-32

Chime Zone Alarms to Outputs

P131E 1-248E Chime Zone Alarms to Output
(Default = All Off)

01-32 = A Chime Zone Alarm will Turn On Output # 1-32

Zone Tamper Alarms to Outputs

P132E 1-248E Zone Tamper Alarms to Output
(Default = 1,2)

01-32 = A Zone Tamper Alarm will Turn On Output # 1-32

Programming Zone Options D

P6133E 1-248E Programming Zone Options D
(Default = All Off)

1 = Zone is Excluded from Activity monitoring
2 = Zone will hold off Arming until Sealed
3 = "Security Interlock" zone

Armed Zone Alarm Beeps to Keypads

P134E 1-248E Armed Zone Alarm Beeps to Keypads
(Default = All On)

01-32 = An Armed Zone Alarm will Beep Keypad #1-32

Stay Mode Zone Alarm Beeps to Keypads

P135E 1-248E Stay Mode Zone Alarm Beeps to Keypads
(Default = All On)

01-32 = A Stay Mode Zone Alarm will Beep Keypad #1-32

24 Hour Zone Alarm Beeps to Keypads

P136E 1-248E 24 Hour Zone Alarm Beeps to Keypads
(Default = All On)

01-32 = A 24 Hour Zone Alarm will Beep Keypad #1-32

Chime Zone Alarm Beeps to Keypads

P137E 1-248E Chime Zone Alarm Beeps to Keypads
(Default = All Off)

01-32 = A Chime Zone Alarm will Beep Keypad #1-32

Zone Tamper Alarm Beeps to Keypads

P139E 1-248E Zone Tamper Alarm Beeps to Keypads
(Default = All On)

01-32 = A Zone Tamper Alarm will Beep Keypad #1-32

Radio Supervise Alarm Beeps to Keypads

P140E 1-248E Radio Supervise Alarm Beeps to Keypads
(Default = All Off)

01-32 = A Radio Supervise Alarm will Beep Keypad #1-32

Zone Sensor-watch Alarm Beeps to Keypads

P141E 1-248E Zone Sensor-watch Alarm Beeps to Keypads
(Default = All Off)

01-32 = A Zone Sensor-watch Alarm will Beep Keypad #1-32

Armed Zone Entry Delay Beeps to Keypads

P142E 1-248E Armed Zone Entry Delay Beeps to Keypads

(Default = 1)

01-32 = Armed Zone Entry Delay will Beep Keypad #1-32

Stay Mode Entry Delay Beeps to Keypads

P143E 1-248E Stay Mode Entry Delay Beeps to Keypads

(Default = 1)

01-32 = Stay Mode Entry Delay will Beep Keypad #1-32

Armed Zone Entry Delay Times

P144E 1-248E Armed Zone Entry Delay Times - Value 0-9999 seconds
(Default Zone # 1 = 20 Seconds, Zones # 2-64 = 0)

Stay Mode Entry Delay Times

P145E 1-248E Stay Mode Entry Delay Times - Value 0-9999 seconds
(Default Zones # 1-4 = 20 Seconds, Zones # 5-64 = 0)

Zone Re-trigger Count

P146E 1-248E Zone Re-Trigger Count - Value 0-15 (Maximum number of times a zone can re-trigger during armed state. 0=Unlimited Triggers)
(Default = 0)

Zone Reports using this Area

P147E 1-248E Zone Reports using this Area - Value 0-32

Zone Alarm Contact ID Reporting Codes

P157E 1-248E Zone Alarm Contact ID Reporting Code - (Default = 130)

Zone Near Alarm Contact ID Reporting Codes

P158E 1-248E Zone Near Alarm Contact ID Reporting Code - (Default = 138)

Zone Intrusion Verified Alarm Contact ID Reporting Codes

P159E 1-248E Zone Intrusion Verified Alarm Contact ID Reporting Code - (Default = 139)

Zone Alarm Voice Message Number

P160E 1-248E Zone Alarm Voice Message Number - Value 0-99 (Default = 1)

Away Zone Entry Delay to Outputs

P161E 1-248E Away Zone Entry Delay to Outputs

(Default = All Off)

01-32 = Armed Zone Entry Delay to output #1-32

Stay Mode Entry Delay to Outputs

P162E 1-248E Stay Mode Entry Delay Beeps to Outputs

(Default = All Off)

01-32 = Stay Mode Entry Delay to output #1-32

Sensor-Watch Timer

P163E 1-248E Sensor-Watch Timer - 0-9999 Minutes (Default = 7200 minutes [120 Hours])

Enrolling Radio Zone Codes

P164E 1-248E Learn Radio Zone Codes

Delete a Specific Radio Zone Code

P165E 1-248E Delete a Specific Radio Zone Code

Find Radio Zone memory Location

P166E This will find the zone # of any Radio Zone code stored in the panel

After P166E press enter to start the find process

Zone Near Alarm to Outputs

P167E 1-248E Zone Near Alarm to Outputs

(Default = All Off)

01-32 = Zone Near Alarm to output #1-32

Zone Confirmed Alarm to Outputs

P168E 1-248E Zone Confirmed Alarm to Outputs

(Default = All Off)

01-32 = Zone Confirmed Alarm to output #1-32

Program LCD KP "Zone" Name

P169E 1-248E Program LCD KP "Zone" Name Text

Access Control Door Monitor Linked to Output

P6174E 1-248E Access Control Door Monitor Linked to Output

(Default = All 0)

01-32 = Output #1-32 (0 = Disabled)

Access Control Options

P6175E 1-248E Access Control Options

(Default = 0)

0 = Disabled, no access monitor options

1 = Access Door Monitoring

2 = Access Door REX button

3 = Egress button - hold door open

4 = Global Fire Egress - hold all Access doors open

5 = Global Egress - hold all Egress doors open

Access Control Options B

P6176E 1-248E Access Control Options B

(Default = None)

1 = Report access violation as output # not zone #

2 = Hide this zone on the web status page

3 = Zone restore auto-resets Egress outputs

Access Door Open Too Long Beeps to Keypads

P6177E 1-248E Access Door Open Too Long Beeps to Keypads

(Default = All Off)

01-32 = An Access Door left Open too long will Beep Keypad #1-32

		Access Door Forced Open Beeps to Keypads	
P6178E	1-248E	Access Door Forced Open Beeps to Keypads (Default = All Off)	01-32 = An Access Door forced Open twill Beep Keypad #1-32
		Access Door Open Too Long to Outputs	
P6179E	1-248E	Access Door Open Too Long to Outputs (Default = All Off)	01-32 = An Access Door left Open too long will trigger Output #1-32
		Access Door Forced Open to Outputs	
P6180E	1-248E	Access Door Forced Open to Outputs (Default = All Off)	01-32 = An Access Door forced Open twill trigger Output #1-32
+++++Schedules+++++			
		Programming Holidays	
P170E	1-32E	Holidays 1-32 Days - Value = DDMMYY	
		Programming Schedule Days	
P171E	1-32E	Schedule 1-32 Days (Default = All Off)	1 = Sunday 2 = Monday 3 = Tuesday 4 = Wednesday 5 = Thursday 6 = Friday 7 = Saturday 8 = Invert
		Programming Schedule Start & End Times	
P172E	1-32E	Schedule 1-32 Start Time - Value 0000-2359 (Default = 0000)	
P173E	1-32E	Schedule 1-32 End Time - Value 0000-2359 (Default = 0000)	
		Schedule Options	
P174E	1-32E	Schedule 1-32 Options (Default = All Off)	1 = Ignore Holidays 2 = Dormant Schedule (see P1032E)
+++++Communicator+++++			
		Communicator Programming Options	
P175E	1E	Communicator options (Default = None)	1 = Communicator is Enabled 2 = Fax Defeat 3 = Disable Telephone Line Monitoring 4 = DTMF or Pulse Dial (For DTMF, 4&5 must both be OFF) 5 = DTMF or Reverse Pulse Dial (For DTMF, 4&5 must both be OFF) 6 = Send long DTMF tones during dialing 7 = Spare 8 = Spare
		Communicator Programming Options 2	
P175E	2E	Communicator options 2 (Default = 1)	1 = Step number on each call 2 = Send IP reporting path in Poll message (Off= don't send the path data) ## 3 = Spare 4 = Test calls only if armed 5 = Test Time Period is in days 6 = Hold line open following Domestic/Voice report for DTMF control 7 = Ring Timeout (Off = 3 secs, On = 6.5 secs). 8 = Answer After 1 ring for Listen-in Mode
## If Option 2 above is ON the zone location in the poll message will include 001 for Ethernet, 003 for 4G SIM1 or 004 for 4G SIM2 path.			
		Auto-Answer Ring Count	
P175E	3E	Auto-Answer Ring Count - Value 0-99 (Default = 25)	
		Test Call Start Time	
P175E	4E	Test Call Start Time - Value 0000-2359 (Default = 2300)	
		Test Call Time Period	
P175E	5E	Test Time Call Period - Value 0-255 Hours: 0 = No Test (Default = 24)	
		Keypad Listen-in Options	
P175E	6E	Keypad Listen-in Options (Default = 1,2,3,4,5,6,7)	1 = Enabled During Dialling in Disarm State only 2 = Enabled During Dialling in Armed State only 3 = Enabled During Dialling in Stay Mode State only 4 = Enabled Throughout the call in Disarm State only 5 = Enabled Throughout the call in Armed State only 6 = Enabled Throughout the call in Stay Mode State only 7 = Listen-in Enabled when the panel answers a call 8 = Enabled at All Times

Communicator Fail Line Switch Output

P175E	7E	Communicator Fail Line Switch Output - Value = Output number 1 –32
P175E	8E	Dialling Pre-fix Number - Value 1-16 Digits (Default = 0)
P175E	9E	“Panic” Alarm CID Reporting Code - (Default=120)
P175E	10E	“Fire” Alarm CID Reporting Code - (Default=110)
P175E	11E	“Medical” Alarm CID Reporting Code - (Default=100)
P175E	12E	Output “Command Control” Code Number
P175E	13E	Reserved for future use.
P175E	14E	Voice/Domestic Acknowledge Code - Value 1-4 digit code (1-9999) (Default = 0)
P175E	15E	Force Test Call Code - Value 1-4 digit code (1-9999) (Default = 0, Feature disabled)

Programming Voice Board Messages

P176E	1E	Keypad or Radio “Panic” Alarm Voice Message Number - Value 0-99 (Default = 0)
P176E	2E	“Fire” Alarm Voice Message Number - Value 0-99 (Default = 0)
P176E	3E	“Medical” Alarm Voice Message Number - Value 0-99 (Default = 0)
P176E	4E	“Mains Failure” Voice Message Number - Value 0-99 (Default = 0)
P176E	5E	“Mains Restore” Voice Message Number - Value 0-99 (Default = 0)
P176E	6E	“Battery Low” Voice Message Number - Value 0-99 (Default = 0)
P176E	7E	“Battery Restored” Voice Message Number - Value 0-99 (Default = 0)
P176E	8E	“Tamper” (Zone/Radio/System) Voice Message Number - Value 0-99 (Default = 0)
P176E	9E	“Duress Alarm” Voice Message Number - Value 0-99 (Default = 0)
P176E	10E	“Latchkey Disarm” Voice Message Number - Value 0-99 (Default = 0)
P176E	11E	“Manual Test Initiated” Voice Message Number - Value 0-99 (Default = 0)

+++++Telephone Numbers+++++

Programming Telephone Numbers

P181E	1-8E	Programming Telephone Numbers - Value 1-16 Digits (Default = 0)
-------	------	---

Communicator Reporting Formats

P182E	1-8E	Communicator Reporting Formats (Default = 1)
		<ul style="list-style-type: none"> 1 = Contact ID 2 = Domestic Dial 3 = Pager 4 = Speech Dialler 5 = CSV IP Extended (sends 4 digit zone/user field) 6 = Patriot IP 7 = XML IP 8 = CSV IP Normal 9 = DC-09 IP Format 10 = SIA Format 11 = SIA Slow Format

Communicator Reporting Options

P183E	1-8E	Communicator Reporting Options (Default = 1,2)
		<ul style="list-style-type: none"> 1 = Stop Dialling if Kissed off 2 = Monitor Call Progress 3 = Blind Dial 4 = Use Group Numbers for Contact ID Reporting 5 = Stay On-line after Alarm report for Audio Listen-in 6 = Spare 7 = Use the Dialling Pre-fix 8 = Spare

Maximum Dial Attempts per Telephone Number

P184E	1-8E	Maximum Dial Attempts per Telephone Number - Value 0-99 (Default = 20)
-------	------	--

Communicator Reporting Options A

P186E	1-8E	Communicator Opts A (Default = All On)
		<ul style="list-style-type: none"> 1 = Report Mains Failure 2 = Report Battery low 3 = Report Radio Battery Low 4 = Report Line Fail 5 = Report System Tamper 6 = Report Keypad Tamper 7 = Report Zone Tamper 8 = Report Radio Zone Tamper

Communicator Reporting Options B

P187E	1-8E	Communicator Opts B (Default = All On)	1 = Report Duress Alarm 2 = Report Supervised Radio Alarm 3 = Report Zone Sensor-watch Alarm 4 = Report Manual Panic Alarm 5 = Report Manual Fire Alarm 6 = Report Manual Medical Alarm 7 = Report Radio Pendant Panic Alarm 8 = Report Zone Bypasses
--------------	-------------	--	--

Communicator Reporting Options C

P188E	1-8E	Communicator Opts C (Default = 1,6,8)	1 = Report Arm/Disarm 2 = Report Stay Mode Arm/Disarm 3 = Report Disarm only after an Activation 4 = Report Stay Mode Disarm only after an Activation 5 = Report Stay Mode Zone Alarms 6 = Report Access to Program Mode 7 = Report 24 Hour Alarms when set to Domestic/Voice mode 8 = Report Zone Restores
--------------	-------------	---	--

Communicator Reporting Options D

P189E	1-8E	Communicator Opts D (Default = 3,4,5)	1 = Report Latchkey Disarm 2 = Report Delinquent 3 = Report Tests 4 = Report Fuse Failure 5 = Report Output 1 or 2 Fail 6 = Report RTC Time changed 7 = Report Keypad Buss Trouble 8 = Spare
--------------	-------------	---	---

+++++SIA Alarm Report Codes+++++

(SIA event codes are entered by programming a value from the chart on Page 23. For example, to send the SIA "Panic Alarm" code when a keypad panic is generated you must enter a value of "6" at location P197E1E)

Zone Alarm SIA Reporting Codes

P196E	1-248E	Zone Alarm SIA Reporting Code - (Default value = 1, Alarm Event Code BA)
--------------	---------------	---

"Panic" Alarm SIA Reporting Code

P197E	1E	"Panic" Alarm SIA Reporting Code - (Default value = 6, Panic Alarm Event Code PA)
--------------	-----------	--

"Fire" Alarm SIA Reporting Code

P197E	2E	"Fire" Alarm SIA Reporting Code - (Default value = 4, Fire Alarm Event Code FA)
--------------	-----------	--

"Medical" Alarm SIA Reporting Code

P197E	3E	"Medical" Alarm SIA Reporting Code - (Default value = 5, Medical Alarm Event Code MA)
--------------	-----------	--

+++++Panel Diagnostic & Default Options+++++

Display Panel Software Version Number

P200E	1E	Display the Panel Software Version Number
--------------	-----------	--

Display Keypad Address Number

P200E	2E	Display Keypad Address Number
--------------	-----------	--------------------------------------

Display Areas Assigned to this Keypad

P200E	3E	Display Areas Assigned to this Keypad
--------------	-----------	--

Display Active Schedules

P200E	4E	Display Active Schedules
--------------	-----------	---------------------------------

Display Battery Voltage

P200E	5E	Display Battery Voltage
--------------	-----------	--------------------------------

Walk Test Mode

P200E	6E	Walk Test Mode
--------------	-----------	-----------------------

Update "Firmware" to LCD KP, Zone and Output Expanders

P200E	7E	Update "Firmware" to LCD KP, Zone and Output Expanders
--------------	-----------	---

Update "Text Files" to LCD Keypads

P200E	8E	Update "text Files" to LCD Keypads
--------------	-----------	---

Restore User & Installer Codes plus Telephone Numbers to Defaults

P200E	9E	Restore User/Installer Codes & Telephone #'s to Default Values
--------------	-----------	---

Restore All Factory Defaults

P200E	10E	Restore All Factory Defaults (excludes LCD text)
--------------	------------	---

Clear Alarm Memory Buffer

P200E	11E	Clear Alarm Memory Buffer
--------------	------------	----------------------------------

Default ALL LCD text

P200E	12E	Default ALL LCD text.
--------------	------------	------------------------------

		Read RSSI from Pendants and Wireless Zones	
P200E	14E	Read RSSI from Pendants and Wireless Zones ## NOTE: Currently not available for the INFINITY Range of Products.##	
P200E	15E	Reset Keypad Bus to restart all bus connected devices	Reset Keypad Bus
P200E	16E	Update EC-KP Firmware for all EC-KP's connected to the Keypad Bus	Update EC-KP firmware
P200E	17E1234E	Reset ALL Site/User details on the AAP Server to allow new ownership NOTE: The Panel MUST have an internet connection to work.	Clear ALL Site/User details on the APP Server for this panel
P200E	18E	4G Modem Signal Strength	4G Modem Signal Strength
P200E	19E	4G Modem State <u>State Table</u> 0 = MODEM Initialising 1 = MODEM not detected 2 = MODEM reset 3 = MODEM get info 4 = MODEM power-up 5 = MODEM get SIM status 6 = MODEM SIM ready 7 = MODEM SIM not ready 8 = MODEM SIM unknown response 9 = MODEM SIM error 10 = MODEM registering with network 11 = MODEM network register error 12 = MODEM setup cloud certificate key 13 = MODEM cloud certificate key error 14 = MODEM cloud configuration 15 = MODEM cloud configuration error 16 = MODEM connecting to cloud 17 = MODEM cloud connection error 18 = MODEM cloud active and running 19 = MODEM no cloud active and running in idle state (Ethernet is the primary connection) 20 = MODEM timeout 21 = MODEM shutdown (only for testing) 22 = MODEM network disconnect 23 = MODEM running in idle state, waiting for Ethernet link verification 24 = MODEM panel firmware update requested 25 = MODEM panel firmware update, waiting for file system verification 26 = MODEM panel firmware update in progress 27 = MODEM power down 252 = MODEM communication operating in transparent mode (only for testing) 253 = MODEM no acknowledge to modem command 254 = MODEM testing 255 = MODEM unknown status	4G Modem State
+++++IP Alarm Setup+++++			
P201E	1E	Control Panel IP Address (Can also be viewed by pressing the number "9" for 5 seconds in normal mode)	Panel IP Address
P201E	2E	IP Gateway Address (Default = 000.000.000.000)	IP Gateway Address
P201E	3E	IP Subnet Mask (Default = 255.255.255.000)	IP Subnet Mask
P201E	4E	IP Setup Options (Default = All Off) 1 = DHCP/Manual Panel IP address (Off = Automatic DHCP) 2 = Enable Ethernet Test 3 = Sync Panel to Internet Clock 4 = Enable Serial over IP Communications 5 = Disable Cloud Connection (On = No Cloud connection) 6 = Disable Web Pages (On = Web Pages disabled) 7 = Spare 8 = Spare	IP Setup Options

P201E	5E	Show Panel MAC Address (Can also be viewed by pressing the number "8" for 5 seconds in normal mode)	Show Panel MAC Address
P201E	6E	CSV IP Name	CSV IP Name
P201E	7E	CSV IP Password	CSV IP Password
P201E	8E	Alternative (Secondary) Gateway (Default = 000.000.000.000)	Alternative Gateway
P201E	9E	DNS 1 (Default: 8.8.8.8)	Primary DNS Server
P201E	10E	DNS 2 (Default: 8.8.4.4)	Secondary DNS Server
P201E	11E	NTP 1 (Default: 0.nz.pool.ntp.org)	Primary Time Server
P201E	12E	NTP 2 (Default: 1.nz.pool.ntp.org)	Secondary Time Server
P201E	13E	Serial over IP Port (Default: 9000)	Serial over IP Port
P201E	14E	Web Port Number (Default: 80)	Web Port Number
P201E	15E	EC-i 4G APN Setting (NOTE: address only available on EC-LCD)	EC-i 4G APN Setting
P202E	1-8E	IP Reporting Poll Timer (0-9999 minutes)	IP Reporting Poll Timer
P203E	1-8E	Monitoring IP Reporting Number/URL (000.000.000.000)	Monitoring IP Reporting Number/URL
P204E	1-8E	IP Reporting Port Number	IP Reporting Port Number
P205E	1-8E	IP Reporting Poll Event Code	IP Reporting Port Number

Zone Expander DIP Switch settings

Expanders - Zone Doubling	Expanders - NO Zone Doubling	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	DIP SW6	DIP SW7	DIP SW8
Not used	EXP # 1 (zones 9-16)	<u>ON</u>	off	off	off	off			
EXP # 2 (zones 17-32)	EXP # 2 (zones 17-24)	off	<u>ON</u>	off	off	off			
Not used	EXP # 3 (zones 25-32)	<u>ON</u>	<u>ON</u>	off	off	off			
EXP # 4 (zones 33-48)	EXP # 4 (zones 33-40)	off	off	<u>ON</u>	off	off			
Not used	EXP # 5 (zones 41-48)	<u>ON</u>	off	<u>ON</u>	off	off			
EXP # 6 (zones 49-64)	EXP # 6 (zones 49-56)	off	<u>ON</u>	<u>ON</u>	off	off			
Not used	EXP # 7 (zones 57-64)	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	off			
EXP # 8 (zones 65-80)	EXP # 8 (zones 65-72)	off	off	off	<u>ON</u>	off			
Not used	EXP # 9 (zones 73-80)	<u>ON</u>	off	off	<u>ON</u>	off			
EXP # 10 (zones 81-96)	EXP # 10 (zones 81-88)	off	<u>ON</u>	off	<u>ON</u>	off			
Not used	EXP # 11 (zones 89-96)	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	off			
EXP # 12 (zones 97-112)	EXP # 12 (zones 97-104)	off	off	<u>ON</u>	<u>ON</u>	off			
Not used	EXP # 13 (zones 105-112)	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	off			
EXP # 14 (zones 113-128)	EXP # 14 (zones 113-120)	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	off			
Not used	EXP # 15 (zones 121-128)	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	off			
EXP # 16 (zones 129-144)	EXP # 16 (zones 129-136)	off	off	off	off	<u>ON</u>			
Not used	EXP # 17 (zones 137-144)	<u>ON</u>	off	off	off	<u>ON</u>			
EXP # 18 (zones 145-160)	EXP # 18 (zones 145-152)	off	<u>ON</u>	off	off	<u>ON</u>			
Not used	EXP # 19 (zones 153-160)	<u>ON</u>	<u>ON</u>	off	off	<u>ON</u>			
EXP # 20 (zones 161-176)	EXP # 20 (zones 161-168)	off	off	<u>ON</u>	off	<u>ON</u>			
Not used	EXP # 21 (zones 169-176)	<u>ON</u>	off	<u>ON</u>	off	<u>ON</u>			
EXP # 22 (zones 177-192)	EXP # 22 (zones 177-184)	off	<u>ON</u>	<u>ON</u>	off	<u>ON</u>			
Not used	EXP # 23 (zones 185-192)	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	<u>ON</u>			
EXP # 24 (zones 193-208)	EXP # 24 (zones 193-200)	off	off	off	<u>ON</u>	<u>ON</u>			
Not used	EXP # 25 (zones 201-208)	<u>ON</u>	off	off	<u>ON</u>	<u>ON</u>			
EXP # 26 (zones 209-224)	EXP # 26 (zones 209-216)	off	<u>ON</u>	off	<u>ON</u>	<u>ON</u>			
Not used	EXP # 27 (zones 217-224)	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	<u>ON</u>			
EXP # 28 (zones 225-240)	EXP # 28 (zones 225-232)	off	off	<u>ON</u>	<u>ON</u>	<u>ON</u>			
Not used	EXP # 29 (zones 233-240)	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	<u>ON</u>			
EXP # 30 (zones 241-248)	EXP # 30 (zones 241-248)	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>			
	On Board Tamper Ignored								<u>ON</u>
	On Board Tamper Active								off

Output Expander DIP Switch settings

Output Expander Number	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	DIP SW6	DIP SW7	DIP SW8
O/P EXP # 1	off	off	off	Follows Outputs 1-4				
O/P EXP # 2	<u>ON</u>	off	off	Follows Outputs 5-8				
O/P EXP # 3	off	<u>ON</u>	off	Follows Outputs 9-12				
O/P EXP # 4	<u>ON</u>	<u>ON</u>	off	Follows Outputs 13-16				
O/P EXP # 5	off	off	<u>ON</u>	Follows Outputs 17-20				
O/P EXP # 6	<u>ON</u>	off	<u>ON</u>	Follows Outputs 21-24				
O/P EXP # 7	off	<u>ON</u>	<u>ON</u>	Follows Outputs 25-28				
O/P EXP # 8	<u>ON</u>	<u>ON</u>	<u>ON</u>	Follows Outputs 29-32				
On Board Tamper Ignored								<u>ON</u>
On Board Tamper Active								off

DIP switch number 8 disables the on-board tamper input if not required.
DIP Switches 4, 5, 6, & 7 are currently unused.

There is an LED associated with every output. They are labelled OUTPUT 1-4.
LED 1 relates to output 1 through to LED 4 relates to output 4.

At power up the LED's will cycle in numerical order back and forth until communications is established with the main control panel. If there is an address clash (eg two output expanders set to the same address number) they will continue to cycle until the clash is resolved by changing the switches on one of the expanders.

Under normal conditions the LED's will be off when the output is off. When an LED is on that indicates the associated relay is on.

The output expander can be powered from the main control panel (as shown on the connection diagram on the previous page) or there is an optional plug in 1A power supply module that can be fitted to the output expander. When the optional power supply module is fitted the 13.8V (POS) from the panel must not be connected, only the 0V from the main control panel should be connected to the output expander 0V.

EC-A2 Interface DIP Switch settings

EC-A2 Keypad Address	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	Relay Mapped to	Input Mapped to
Keypad Address # 1	off	off	off	off	off	Output 1	Input 1
Keypad Address # 2	<u>ON</u>	off	off	off	off	Output 2	Input 2
Keypad Address # 3	off	<u>ON</u>	off	off	off	Output 3	Input 3
Keypad Address # 4	<u>ON</u>	<u>ON</u>	off	off	off	Output 4	Input 4
Keypad Address # 5	off	off	<u>ON</u>	off	off	Output 5	Input 5
Keypad Address # 6	<u>ON</u>	off	<u>ON</u>	off	off	Output 6	Input 6
Keypad Address # 7	off	<u>ON</u>	<u>ON</u>	off	off	Output 7	Input 7
Keypad Address # 8	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	off	Output 8	Input 8
Keypad Address # 9	off	off	off	<u>ON</u>	off	Output 9	Input 9
Keypad Address # 10	<u>ON</u>	off	off	<u>ON</u>	off	Output 10	Input 10
Keypad Address # 11	off	<u>ON</u>	off	<u>ON</u>	off	Output 11	Input 11
Keypad Address # 12	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	off	Output 12	Input 12
Keypad Address # 13	off	off	<u>ON</u>	<u>ON</u>	off	Output 13	Input 13
Keypad Address # 14	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	off	Output 14	Input 14
Keypad Address # 15	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	Output 15	Input 15
Keypad Address # 16	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	Output 16	Input 16
Keypad Address # 17	off	off	off	off	<u>ON</u>	Output 17	Input 17
Keypad Address # 18	<u>ON</u>	off	off	off	<u>ON</u>	Output 18	Input 18
Keypad Address # 19	off	<u>ON</u>	off	off	<u>ON</u>	Output 19	Input 19
Keypad Address # 20	<u>ON</u>	<u>ON</u>	off	off	<u>ON</u>	Output 20	Input 20
Keypad Address # 21	off	off	<u>ON</u>	off	<u>ON</u>	Output 21	Input 21
Keypad Address # 22	<u>ON</u>	off	<u>ON</u>	off	<u>ON</u>	Output 22	Input 22
Keypad Address # 23	off	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	Output 23	Input 23
Keypad Address # 24	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	Output 24	Input 24
Keypad Address # 25	off	off	off	<u>ON</u>	<u>ON</u>	Output 25	Input 25
Keypad Address # 26	<u>ON</u>	off	off	<u>ON</u>	<u>ON</u>	Output 26	Input 26
Keypad Address # 27	off	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	Output 27	Input 27
Keypad Address # 28	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	Output 28	Input 28
Keypad Address # 29	off	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 29	Input 29
Keypad Address # 30	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 30	Input 30
Keypad Address # 31	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 31	Input 31
Keypad Address # 32	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 32	Input 32

OPTION	DIP SW6	DIP SW7	DIP SW8	
1 Door Controller	off	-		If set to 1 door Wiegand Input 2 unused
2 Door Controller	<u>ON</u>	-		If set to 2 door Wiegand Input 2 is KP address +1
Input is a REX	-	off		If set to 1 door only Input 1 is active, if set to 2 door both inputs are REX
Input is a Zone	-	<u>ON</u>		If set to 1 door only Input 1 is active, if set to 2 door both inputs are zones
Enable EC-A2 Tamper	-	-	off	EC-A2 on-board tamper is active and will trigger an alarm
Disable EC-A2 Tamper	-	-	<u>ON</u>	If DIP SW8 is ON the EC-A2 tamper is disabled

Contact ID Reporting Code Summary

In addition to the programmable Contact ID Event Code assignments defined at P157E, P158E, P159E, P175E (9E-11E) there are a number of fixed event codes. The programmable and fixed event codes are all listed in the table below. Associated with the fixed and programmable event codes, there are a number of extension codes, that are also listed below. The list of extension codes is for your reference only and can not be changed in programming. For "Users" Above 998 the panel will report all as user 998 (eg users 998-2000 will all be reported as 998).

Event Type	Event Code	Extension	Comment
System Tamper	137	000	Panel & Sat Tamper etc
Zone Alarm (wired or wireless)	130	001 to 248	Alarm on Zone 1-248
Zone Tamper - Low (short circuit)	383	001 to 248	Zone Input 1-248 short circuit
Zone Tamper - High (open circuit)	383	009 to 248	Zone Input 1-248 open circuit
Zone Tamper - Radio Zone	383	001 to 248	Radio Zone 1-248
Zone Near Alarm	138	001 to 248	Zone Input 1-248
Zone Confirmed Alarm	139	001 to 248	Zone Input 1-248
Radio PIR / Reed Switch Battery Low	384	001 to 248	Radio Zone 1-248
Radio PIR Supervised Alarm	381	001 to 248	Supervised Radio Zone 1-248
Sensor-watch Alarm	391	001 to 248	Zone 1-248
Zone Excludes	570	001 to 248	Exclude Zone 1-248
Keypad Panic (CONTROL+CHIME)	120	001 to 032	Panic at keypad #1-32
Radio-Key Panic	120	101 to 998	Panic by Radio User # 101-2000
Keypad Fire (A+B)	110	001 to 032	Fire Alarm at keypad #1-32
Keypad Medical (B+CHIME)	100	001 to 032	Medical Alarm at keypad #1-32
EC-i Controller Tamper Switch Alarm	137	000	EC-i Tamper Switch Activated
Keypad Tamper Switch Alarm	137	001 to 032	Keypad 1-32 Tamper Switch Activated
Wrong Code Alarm	461	001 to 032	4 Incorrect code entries at KP # 1-32
Arm/Disarm by "ARM key (Quick Arm)	408	000	Arm/Disarm by single button
Arm/Disarm by user code	401	001 to 998	Arm/Disarm by User #1-2000
Arm/Disarm by Radio-key	400	101 to 998	Arm/Disarm by Radio User #101-2000
Arm/Disarm by Key-switch	409	001 to 064	Zone Key-switch # 1-64 Arm/Disarm
Arm/Disarm by DTMF or Up/Download	407	000	Remote Arm/Disarm
Arm by "Security Interlock" Zone	407	001 to 064	Arm by "Security Interlock" zone # 1-64
Arm/Disarm by Time-Zone	403	000	Time-Zone Arm/Disarm
Latchkey Disarm	642	001 to 998	Latchkey User Disarm
Fail to Arm on Time-Zone	455	000	Auto Arm fail
Delinquency Alarm	454	000	System not Armed within # days
Stay Mode Arm/Disarm (part set)	441	000	Arm by "Stay" Button
Stay Mode Arm/Disarm (part set)	441	001 to 998	Stay Mode Arm by User # 1-2000
Stay Mode Arm/Disarm by Key-switch	442	000 to 064	Stay Mode Arm by Zone Key-switch # 1-64
AC Fail	301	000	Mains (AC) fail
Zone Expander AC Fail	301	001-007	AC Fail on Zone exp. 1-7
Output Expander AC Fail	301	101-108	AC Fail on Output exp. 1-8
Wiegand Interface AC Fail	301	201-232	AC Fail on Wiegand IF 1-32
System Battery Low	302	000	Control Panel Battery low
Zone Expander Battery Low	302	001-007	Battery Low on Zone exp. 1-7
Output Expander Battery Low	302	101-108	Battery Low on Output exp. 1-8
Wiegand Interface Battery Low	302	201-232	Battery Low on Wiegand IF 1-32
Checksum Fail (Corrupt EEPROM Data)	303	001-008	Checksum block error
Fuse Fail - Main panel	312	000	Fuse 1 or 2 Fail on ESX-1
Fuse Fail - Zone expander	312	001-007	Fuse Fail on Zone Exp PSU
Fuse Fail - Output expander	312	101-108	Fuse Fail on Output EXP PSU
Fuse Fail - Wiegand IF-2	312	201-232	Fuse Fail on Wiegand IF-2 PSU
Radio-key Battery Low	309	101 to 998	Radio-key User #101-2000 low batt.
Radio-PIR / Reed Switch Battery Low	384	001 to 064	Radio Zone 1-64
Radio Output Device Battery Low	338	001 to 032	Radio Output 1-32
Automatic TEST Calls	602	000	24 hour test
Manual TEST Calls	601	000	User generated Test Call
Phone Line Failure	351	001	Reported when Phone line is restored
IP Communication Failure	351	002	Reported when LAN connection restored
Cloud Server Communication Failure	351	005	Reported when Cloud Comms restored
Permaconn RS232 Failure	351	006	Reported when RS232 Comms restored
4G Communication Failure	351	007	Reported when 4G Comms restored
Duress Alarm	121	001 to 032	Duress at Keypad #1-32
Program Mode Entry	627	000	Program Mode entered
Program Mode Exit	628	000	Program Mode exited
Zone Expander Tamper Alarm	145	001-007	Zone expander board Tamper Alarm
Output Expander Tamper Alarm	341	001-008	Output expander board Tamper Alarm

Wiegand IF-2 Tamper Alarm	137	001-032	Wiegand IF-2 board Tamper Alarm
Zone Expander Module Fail	333	001-007	Zone exp. 1-7 Fail
Output Expander Module Fail	333	101-108	Output exp. 1-8 Fail
Wiegand Interface Module Fail	333	201-232	Wiegand IF 1-32 fail
FW2-CAN bus RF Module Fail	333	100	The FW2 CAN bus RF Module is missing
Output 1 or 2 Tamper	323	001 or 002	O/P 1 or 2 wires cut.
Time & Date Changed	625	000	Time & Date has been changed
Keypad Bus Trouble	330	001 to 032	Keypad device 1-32 offline
System Reset	305	000	Panel has rebooted
RF Receiver jam detected	344	000	RF Jamming Detected
Dialler Failure	354	000	Failure to get kiss off
IP Failure	356	000	Failure to send IP Poll
Access Door Forced Alarm	423	001 to 032	The access door has been forced open
Access Door left open too long Alarm	426	001 to 032	The access door has been left open.
Access Door opened by Fire alarm input	125	001 to 064	Free Egress granted during a Fire Alarm

SIA Reporting Code Summary

Most of the SIA Event Codes are fixed within the panel but some locations such as zones at P196E (1-248E) and Panic/Fire/Medical at P197E (1-3E) can have a user defined report code from the table below. To follow are the default SIA reporting codes. Unlike CID, users 1-2000 will be reported as 1-2000 in SIA format.

Event Type

Armed, 24 hour & Near Zone Alarms (programmable P196E)
 Zone Verified Alarm Activated
 Zone Bypassed
 Zone Tamper Activated
 Sensor-Watch Fail
 Radio Zone Supervise Fail
 Pendant or Radio Zone Low Battery
 Keypad or Pendant Panic Alarm (programmable P197E1E)
 Keypad Fire Alarm (programmable P197E2E)
 Medical Alarm (programmable P197E3E)
 Duress Alarm
 Panel, Keypad or Wiegand IF-2 Tamper Switch Activated
 Zone Expander Tamper Activated
 Output Expander Tamper Activated
 Zone, Output or Wiegand IF-2 fail
 Battery Low (see CID for extension numbers)
 AC Fail (see CID for extension numbers)
 Output Tamper Alarm (O/P 1 & 2 only)
 12V Output (fuse) Failure
 Phone Line Fail
 Automatic Test Message
 Manual Test Call
 Area Delinquency Alarm
 Excessive Code Attempts Alarm
 Armed by User, Pendant, ARM button, DTMF or PC
 Area Armed by Key-Switch
 Area Armed by Time Zone
 Stay Mode Armed by User, Pendant, KS, STAY Button
 Fail to Arm by Time-Zone
 Program Mode Entry/Exit
 Checksum Fail (Corrupt EEPROM Data)
 Time Changed
 Keypad Bus Trouble
 Dialler Failure (No Kiss off)
 RF Interference (jamming) Detected
 IP Poll Failure

 Access Door Forced Alarm
 Access Door Left Open too Long
 Egress Door Opened by Pushbutton or Fire alarm

SIA Alarm Code

BA
 BV
 BB
 BT
 NA
 BZ
 XT
 PA
 FA
 MA
 HA
 TA
 ES
 TT
 EM
 YT
 AT
 YA
 YP
 LT
 RP
 RX
 CD
 JA
 CL
 CS
 CA
 CG
 CI
 LB
 YF
 JT
 IA
 YC
 XQ
 NT

 DF
 DN
 DG

SIA Restore Code

BH
 BH
 BU
 BJ
 NS
 BR
 XR
 PH
 FH
 MH
 HH
 TR
 EJ
 TJ
 EN
 YR
 AR
 YH
 YQ
 LR

 CT
 JP
 OP
 OS
 OA
 OG

 LX

 IR

 XH
 NR

 DR
 DH
 DY

When you program one of the numbers in column 2 below at any of the addresses at P196E or P197E then all of the SIA codes associated with that event type will automatically be loaded, eg if Zone 10 (P196E10E) was programmed with a “4”, then when zone 10 activates it will send the fire alarm (FA) and the fire alarm restore (FH) and if zone 10 was bypassed it will send the fire bypass (FB) and the fire un-bypass (FU).

CHART FOR THE PROGRAMMABLE SIA EVENT CODES									
Event Description	Program Number	Alarm	Restore	Bypass	Un-Bypass	Trouble	Trouble Restore	Near Alarm	Verified Alarm
Burglary	1	BA	BH	BB	BU	BT	BJ	BA	BV
Un-typed Alarm	2	UA	UH	UB	UU	UT	UJ	-	-
Hold-up	3	HA	HH	HB	HU	HT	HJ	-	-
Fire	4	FA	FH	FB	FU	FT	FJ	FA	FM
Medical	5	MA	MH	MB	MU	MT	MJ	-	-
Panic	6	PA	PH	PB	PU	PT	PJ	-	-
Emergency	7	QA	QH	QB	QU	QT	QJ	-	-
Gas	8	GA	GH	GB	GU	GT	GJ	-	-
Sprinkler	9	SA	SH	SB	SU	ST	SJ	-	-
Water	10	WA	WH	WB	WU	WT	WJ	-	-
Heat	11	KA	KH	KB	KU	KT	KJ	-	-
Freeze	12	ZA	ZH	ZB	ZU	ZT	ZJ	-	-
Equipment	13	IA	IR	-	-	-	-	-	-
Equip. Tamper	14	TA	TH	TB	TU	TT	TJ	-	-

ECi Software update schedule