



WT1020 3G

3G CELLULAR UNIT

You will need a Spark, Vodafone or 2Degrees SIM card for installation.

SETUP

1. Insert your SIM card into the SIM hold behind the cover, on the back of the WT1020 3G. Please ensure the SIM card has:
 - A, been activated. This is done by putting the SIM card in a cellphone and going through the commands.
 - B, unlocked and password turned off. This is also done using a cellphone, through it's menu.
 - C, credit. Each call made from the Panel will incur usual cellphone calling rates.

Please note a Data only SIM card will not work.
If your having trouble activating the SIM card ask your Cellular provider to help.
2. Wire the white Telecable into the 'Line In' terminal of the alarm panel. Then plug the other end into one of the RJ-11 sockets on the WT1020 3G.
3. Wire the Power Cable in to one of the alarms 12 volt outlets (red to +12V, black to Gnd/0V) Then Plug it into the WT1020. It is recommended to use the 12 volt outlet next to the zone terminals.
4. Power the alarm panel up, now it's time to program. For programming instructions please follow the QUICKFIT hook-up sheet, or your panels programming manual.