## Diagnostic Remote

AAP E-LOOP REMOTE

Bi-directional remote compatible with AAP E-LOOP KIT R & AAP E-LOOP KIT C





e-Loop, press connect, and you are ready to go. With easy to navigate menu functions you can:

- Alter the trip level
- 2 Adjust the sensitivity of each Axis
- 3 Calibrate the e-Loop
- 4 Change operational mode
- **5** Monitor operation in real time
- **6** Check for background radio interference

