

# Access Control Tool

PROX READER USB

125Khz reader for simple addition of prox cards/tags to your EC-i system

EliteControl 



Connect the PROX READER USB to your computer with the supplied USB cable to simply add proximity tags/cards to your EC-i security & control system. Ideal for issuing prox tags/cards in high turnover staff/member applications.



Compatible with

PROX EM4100

PROX CARD

2 Year Warranty

  
**Arrowhead**  
Alarm Products

**Proudly Supplied by Arrowhead Alarm Products**  
1A Emirali Road, Silverdale, 0932, Auckland, New Zealand  
[www.aap.co.nz](http://www.aap.co.nz)