
AAP-EM Smart Emergency Door Release



Insert Tool Here To Reset

| Dipswitch Positions | | |
|---------------------|-------|---|
| | 1 OFF | Alarm Activation Colour = Green When activated the unit will flash green |
| ~ | 1 ON | Alarm Activation Colour = Red When activated the unit will flash red |
| N | 2 OFF | Status Light Disabled No status light |
| N | 2 ON | Status Light Enabled Every 5 seconds lights flash green |
| ო | 3 OFF | Backlight is Disabled No white standby light |
| m | 3 ON | Backlight is Enabled White light on when in standby |
| 4 | 4 OFF | Buzzer is Disabled No sound |
| 4 | 4 ON | Buzzer is Enabled Buzzer will sound when activated |

Specifications:


Voltage Input 10-30VDC

Current Max. 50mA Standby 15mA Activation

Relay Contacts Relay 1: 2A, 30VDC Relay B: 2A, 30VDC ARROWHEAD ALARM PRODUCTS Ltd. 344b Rosedale Rd, Albany, Auckland. Ph. 09 414 0085 www.aap.co.nz v2.0







Wiring Example

